



WaterBoss 300 - Exploded View

Points "A" screw together
O-Ring "B" slides over valve seat (3)
Shaft at "C" passes through valve body and link actuator to "C"
E-Ring (15) snaps over shaft at "D"

WaterBoss 300 - Parts List

1 – Nozzle Shroud	10 – Valve Stem Bushing
2 – Nozzle*	11 – Valve Body
3 – Valve Seat	12 – Trigger
4 – "O"-Ring	13 – Link Actuator
5 – Valve Stem	14 – Stainless Steel Washer
6 – Valve Guide	15 – "E"-Ring (2 required)
7 – Stainless Steel Spring	16 – Housing
8 – Spring Guide	17 – Inlet Pipe
9 – "O"-Ring	

WaterBoss long Trigger	(WB-300-1/2-L)
WaterBoss short Trigger	(WB-300-1/2-S)
Repair Kit "A" contains parts 1 – 4	(WB-RK-300-A)
Repair Kit "B" contains parts 1 – 10 & 12 – 16	(WB-RK-300-B)

*300 Series has two nozzle sizes. The standard nozzle has a small "+" on the front face. The additional nozzle tip is designed to reduce water consumption in gallons used per minute

Distributed by:



Glomatek Corporation
6574 N State Rd 7, Unit 250
Coconut Creek, FL 33073 USA

Tel: +1 954.861.0181 | **Fax:** +1 954.653.3148
info@glomatek.com | www.glomatek.com