



**WaterBoss 750 - Exploded View**

Points "A" screw together  
O-Ring "B" slides over valve seat (3)  
Shaft at "C" passes through valve body and link actuator to "C"  
E-Ring (15) snaps over shaft at "D"

**WaterBoss 750 - Parts List**

- |                            |                             |
|----------------------------|-----------------------------|
| 1 – Nozzle Shroud          | 10 – Valve Stem Bushing     |
| 2 – Nozzle*                | 11 – Valve Body             |
| 3 – Valve Seat             | 12 – Trigger                |
| 4 – "O"-Ring               | 13 – Link Actuator          |
| 5 – Valve Stem             | 14 – Stainless Steel Washer |
| 6 – Valve Guide            | 15 – "E"-Ring (2 required)  |
| 7 – Stainless Steel Spring | 16 – Housing                |
| 8 – Spring Guide           | 17 – Inlet Pipe             |
| 9 – "O"-Ring               |                             |

WaterBoss long Trigger  
WaterBoss short Trigger  
Repair Kit "A" contains parts 1 – 4  
Repair Kit "B" contains parts 1 – 10 & 12 – 16

**(WB-750-3/8-L)**  
**(WB-750-3/8-S)**  
**(WB-750-RK-A)**  
**(WB-RK-750-B)**

Distributed by:



**Glomatek Corporation**  
6574 N State Rd 7, Unit 250  
Coconut Creek, FL 33073 USA

**Tel:** +1 954.861.0181 | **Fax:** +1 954.653.3148  
info@glomatek.com | www.glomatek.com